

The Perfect Temperature

IN EVERY ROOM

Get to know us: pros@flair.co flair.co/pros



Flair Puck

FEATURES	 Monitors room temperature and controls Flair Smart Vents, mini splits, window ACs, and portables Control from your phone, tablet, or computer anywhere in the world Auto Away - saves energy when you are away Adjust the temperature by rotating the Puck - no smartphone required Infrared (IR) control for over 200 brands of mini splits, portables, and ACs Set weekly schedules on a room-by-room basis Puck Pro model has heat staging features that qualify mini split systems for rebates Wireless or wired installation options (first Puck must be wired)
SPECS	 E Ink display Wired power adapter (1st Puck must be wired, the rest can use batteries) 2 x AAA batteries (included) Temperature sensor 915 MHz low power radio 2.4 GHz Wi-Fi 4 year professional warranty Humidity sensor 4 year professional warranty
INTEGRATIONS	Image: Norks with with with with with with with with

Honeywell

ecobee



G Nest